



Safety warnings and Instructions

Read all instructions in this User Guide carefully before use to operate the device in a safe and correct manner.

The Safety Warnings and Instructions discussed in this User Guide cannot cover all possible situations that could occur during the use of the device. Caution and care must be exercised when using or maintaining an electronic device.

Keep these safety warnings and instructions for future reference as they contain important information.

⚠ Failure to follow these instructions may result in personal injuries.

Device electronic and battery

- Do not use the device with its Cap removed.
- Be careful not to drop the device in water.
- This product contains no user-serviceable parts. Do not attempt to open, modify, disassemble or repair the battery or any component of this device.
- If the device appears to be damaged, modified, disassembled, tampered with, or immersed in liquid after purchase, do not activate the device.
- Do not touch the device, AC Power Adaptor and USB Cable if they overheat, fume, ignite, spark or burn.
- Do not use the device if it has been exposed to excessive heat.
- Do not connect the device through electric wires or other metallic materials. Doing so may cause damage.
- Do not use the device where flammable materials, liquids or gases are present, or under conditions with high oxygen supply. Doing so presents an explosion hazard.
- Device, AC Power Adaptor and USB Cable should not be exposed to any liquid, oils, solvents, etc. Do not touch the device or its parts if it becomes wet or has been immersed in liquids, oils, solvents, etc.

-
- Do not clean the device using liquids, oils, solvents, etc.
 - Caution must be exercised so that foreign materials do not enter the stick insertion part. Do not use device unless foreign particles have been removed.
 - If any fluid leaking from the device comes in contact with skin, wash the affected area, including hands and do not touch eyes. In case any fluid comes in contact with eyes, immediately flush with clean, running water for at least 15 minutes and seek medical attention.
 - Do not use the device if battery is leaking.
 - Only use USB Cable and AC Power Adaptor designed for lil SOLID 2.0. See the Technical Data section of this User Guide for approved Power Adaptor models. Do not use other cables and power adaptors - doing so may result in damage.
 - Charge the device indoors only, as indicated by symbol .

Use and storage

- Only use tobacco sticks specifically designed for lil SOLID device. The performance of the device is

-
- not guaranteed if you use it with other consumables.
- Do not modify tobacco sticks in any way or add any substance to tobacco sticks specifically designed for lil SOLID device. Doing so may cause injury.
 - Keep device, USB Cable, AC Power Adaptor and tobacco sticks out of reach of children and pets at all times. Caution: Parts may be swallowed by children.
 - This device is intended for adult-use only. Children and minors should never use the device under any circumstances.
 - The device and tobacco sticks are prohibited for sale to minors.
 - Do not remove Cap while device is in use or immediately after use as device may be hot. Allow for device to cool before removing Cap.
 - Even if the tobacco stick is removed during use, the heating process continues. To stop it, turn off power by pressing the Button for 2 seconds.
 - Clean the device after cooling.
 - After removing the tobacco stick from the device, do not touch the tobacco portion of the stick as it will be hot after use.

-
- Handle the device with care. Do not drop this device or subject it to strong shock.
 - Storing the device in places with high temperatures (such as inside a vehicle or near heat sources such as radiators or fires), high humidity or low temperatures, may reduce battery performance.
 - Device battery will deplete if left unused for an extended period of time. Recharge the device before use.
 - Tobacco sticks specifically designed for lil SOLID device are single-use. Do not re-insert a used stick into the device. The performance of the device is not guaranteed if used sticks are re-inserted.
 - The tobacco stick should never be lit with a match, lighter, or any other flame source.
 - Tobacco sticks may show spots or discoloration after normal use.
 - Do not insert the device in your mouth.
 - Do not operate the device where use of electronic devices is prohibited.
 - This device is not intended for use by persons with reduced physical, sensory or mental capabilities or

-
- lack of knowledge unless they have been given supervision or instruction to use the product in a safe way and understand the hazards involved.
- Being exposed to sweat, UV rays and chemicals in a repeated manner may discolor the device exterior.
 - Proximity to magnetic field may cause malfunction.

Tobacco and nicotine

- Tobacco sticks contain nicotine, which is addictive. Nicotine is naturally present in tobacco used in tobacco sticks.
- Swallowed tobacco sticks can pose a risk of nicotine intoxication. If tobacco sticks are swallowed, seek medical attention immediately.
- The best way to reduce tobacco-related health risks is to quit tobacco and nicotine use altogether.
- Stopping smoking cigarettes or switching to other nicotine-containing products may require the adjustment of the dosing of certain medicines (e.g. theophylline, clozapine, ropinirole).
- Using nicotine-containing tobacco sticks may cause

side effects such as headache, nausea, throat irritation, or stomatitis. If you experience these symptoms, stop use of the product immediately.

- If you are pregnant, think you may be pregnant, or are breastfeeding, or have heart disease, diabetes, epilepsy, seizures or other serious conditions, you should quit tobacco and nicotine use altogether and consult a health care professional.
- Use of tobacco sticks may cause an allergic reaction. Seek medical attention immediately if you experience any of the following symptoms: swelling of the face, lips, tongue, etc., and/or difficulty breathing.

Reporting of adverse events or incidents

- If you experience any unwanted health effect when using the device, consult a health care professional.
- You can report any adverse event or incident directly by contacting Customer Service Centre at 0800 9153.
- By reporting side effects, you can help provide more information on the safety of this product.